



Home > Products > ProX Stands > Lighting Truss & Crankstands > 10ft Medium Duty Lighting Crank Stand

SKU: XT-LS01C

Permalink:

[Search on Google](#)

10ft Medium Duty Lighting Crank Stand

[Find A Dealer](#)

Product Images



[Download Product Images](#)

Our Products And You

[Submit your story](#)

ProX XT-LS01C 10ft Medium Duty Lighting Crank Stand

Description

The ProX XT-LS01C Medium duty crank stand used in conjunction with T-adapters and Trussing(***Sold Separately***) Allows you to mount and raise your lights to a maximum of 10Ft.

MAX VERT LOAD: 180 Lbs.

SAFETY INSTRUCTIONS

To avoid problems a competent person should inspect all rigging hardware, stands and equipment before each use and periodically do a major inspection for signs of wear, abuse, and general adequacy, as well as perform any manufacturer recommended preventive maintenance on schedule. Observe all warnings and usage instructions in the full manual. Use at your own risk.

Features

Basic Usage:

1. Ensure that the stand is positioned on hard stable surface, in suitable location, on firm ground and clear of overhead obstacles.
2. Stabilize legs before lifting the tower or any load.
3. When outdoors, secure the tower with braces or cables, in case of wind.
4. Check the cable, it should not show damaged or flattened areas nor broken strands.

Using the Winch:

1. For Lifting the tower, turn the winch handle clockwise.
2. For lowering the tower, turn the winch handle counter-clockwise.

Safety Notes:

1. Loading on truss and stands should comply with rated weights.
2. Lock all the safety mechanisms (safety pins, knobs)
3. Loads must be centered & balanced on each lifting unit.
4. Safety chains must be installed on each item attached to unit.
5. Leave a safety perimeter with a radius 5ft greater than the maximum height of the stands during lifting and lowering of loads.
6. During transport, close all the sections and lock the lifting carriage.
7. Do not attempt to move the stand when loaded or in extended position.

Service Notes:

1. Servicing and repairs must be made by qualified persons.

2. Cable, pulleys and telescopic masts must be inspected before each use. Any damaged cable must be replaced immediately.
3. Annual inspection by an authorized technician is suggested.

Exterior Dimensions & Weight

Weight: 25.00 lbs

Shipping Dimensions & Weight

Box 1 of 1: 14.00"H x 9.00"W x 69.00"L - Shipping Weight: 34.00 lbs

Suggested Shipping Method: Parcel

UPC

741459147488

Our Products and You

Submit your
story

Commonly Asked Questions

+ Where can I buy one?

[submit a question](#)

Customer Testimonials

What did you think

Related Products




Fusion RGBWA Par 36x 1W LED Slim Par White Housing

SKU: X-PAR36RGBWA1WWIRC



14 Ft Heavy-duty Lighting Crank Stand for Lifting Truss 220 lbs Capacity Incl 5ft T-Bar

SKU: XT-CRANK14FT-220



Set of (2) 10 Ft. DJ Stage Lighting Truss Stands System Includes (2) T-Adapters and (2) I-Beam Segments

SKU: T-LS31M



10-Foot Height Adjustable Portable Crank Lighting Stand System with included 2x T-Bars Triangle Truss for 5ft 10ft 15ft Width

SKU: T-LS35C



10' Ft. High Performance Dual 1/4" TS Male to Dual XLR Male Unbalanced Audio Cable
SKU: XC-DPXM10